

Evaluation of Filter Media for Alpha Continuous Air Monitoring in the Ultrafine Particle Size Range

Health Physics Society – 54th Annual Meeting
Session WPM G – Aerosol Measurements
Minneapolis, Minnesota
July 15, 2009

Mark D. Hoover (NIOSH, Morgantown, WV)

David Baltz (Bladewerx LLC, Rio Rancho, NM)

Benjamin C. Eimer (EG&G Technical Services, Pittsburgh, PA)

Samy Rengasamy (NIOSH, Pittsburgh, PA)



The findings and conclusions in this presentation are those of the authors and do not necessarily represent the views of the National Institute for Occupational Safety and Health.

Mention of company names or products does not constitute endorsement by NIOSH.



Contents

- **Genesis of the filter efficiency question**
 - Historical perspective and recent observation of 40% difference in radioactivity counting results between “similar” filter methods
- **Evaluation of filter differences**
 - Composition and construction
 - Pressure drop
 - Penetration efficiency
- **Opportunities to apply lessons learned**
 - Selection of appropriate filter media
 - Simple steps for quality assurance

Uranium mining – historical perspective



Open-pit mining




Underground mining



The U.S. Radiation Exposure Compensation Program has paid \$643,000,000* in compensation to date to uranium miners / millers / ore transporters


*DOJ program data as of 01/13/2009 3

In situ recovery (ISR) – an emerging option



Courtesy of Uranium Resources, Inc. 4

Alpha emissions of radon progeny



From Hoover and Newton, 1993, 2001 5

**Opportunity to build on the
existing NIOSH criteria document**

***A Recommended Standard for
Occupational Exposure to Radon Progeny
in Underground Mines***

October 1987

DHHS (NIOSH) Publication No. 88-101

**Recommended an annual exposure limit of 1 WLM
(lower than the 1971 U.S. limit of 4 WLM)**

Some specific research and development needs for uranium recovery

- **Improve radon/radiation area monitoring**
 - Including real-time alpha spectroscopy
- **Develop personal radon/radiation dosimeters**
- **Develop training tools to improve uranium miner health and safety**

7


State-of-the-art radon-progeny monitors



** SabreBZM shown with optional high-efficiency sample head*

- Based on methods for monitoring airborne plutonium in the workplace
- Have significant real-time advantages over historical batch sampling methods for filtration and retrospective counting of airborne radioactivity

Influence of filter type on spectral quality



From Hoover and Newton, 1993, 2001 9

Characteristics of filter media

Mixed cellulose ester


- Historical filter of choice
- Moderate pressure drop
- Good alpha spectrum
- Somewhat fragile
- e.g., Millipore SMWP

Trak-etch membrane

- Microscopy option
- High pressure drop
- Good alpha spectrum
- Somewhat fragile
- e.g., Nuclepore 0.6 um

Glass fiber filter

- Gross alpha counting use
- Low pressure drop
- Very poor alpha spectrum
- Moderately rugged
- e.g., Gelman A/E glass



Supported MCE

- Acceptable option
- Moderate pressure drop
- Good alpha spectrum
- Rugged
- e.g., Millipore AW19


PTFE membrane

- Option of choice
- Good pressure drop
- Excellent alpha spectrum
- Rugged
- Front / back difference
- e.g., Fluoropore FLMB, Specton 1.5, 5.0, etc.

Cotton fiber filter

- Historical workplace filter
- Low pressure drop
- Very poor alpha spectrum
- Moderately rugged
- e.g., Whatman 41

Physical basis for the Most Penetrating Particle Size (MPPS)



- Larger particles are collection by inertia
- Smaller particles are collected by diffusion
- MPPS occurs where inertial and diffusive collection are minimal

- **MPPS decreases with increasing face velocity**
 - Inertial collection at the old MMP size is increased
 - Residence time for diffusive collection of smaller particles is decreased

Figure from www.cdc.gov/niosh/docs/2003-136/ 11

Experimental design



5 filter media:

Gelman A/E glass
Speclon 1.5 μm PTFE
Speclon 5.0 μm PTFE
Millipore 5.0 μm PTFE
Millipore 5.0 μm SMWP

3 filter face-velocities:

10 cm/s (3 L/min*) (personal sampling)
30 cm/s (9 L/min) (intermediate)
100 cm/s (30 L/min) (area sampling)

TSI Model 3160 Certitest


Fractional-Efficiency Filter Tests:

- Collection efficiency for 10 monodisperse particle diameters:
20, 30, 40, 50, 60, 80,
100, 200, 300, 400 nm

- Pressure drop as a function of face velocity


*flow rate based on 2.54 cm filter diameter 12

Certitest control panel




13

Display of a test in progress




14

Display of a completed test



15


Example for a Most Penetrating Particle Size (MPPS) of approximately 50 nm



16


Example of penetration versus face velocity

Millipore SMWP



17


Influence of face velocity on MMPS



Behavior follows theory.


18

Pressure drop results



19

Penetration results at the MPSS




20

Lessons learned

- Influences of face velocity on pressure drop and collection efficiency follow filtration principles.
- Low filter penetration applicable to workplace aerosols (default assumption of 5 μm aerodynamic diameter) may not apply for environmental aerosols (default assumption of 1 μm aerodynamic diameter) or for ultrafine aerosols.
- Higher than expected particle penetration for the SpecIon 5.0 μm PTFE filter:
 - Indicates the filter is not suitable for alpha CAM applications and
 - Is consistent with lower than expected pressure drop.
- Routine monitoring of pressure drop provides a quality assurance check.
- Comparison of operational results with alternate filtration methods also provides quality assurance.

21





Questions ?

Mark D. Hoover, PhD, CHP, CIH

Division of Respiratory Disease Studies
National Institute for Occupational Safety and Health
Centers for Disease Control and Prevention

1095 Willowdale Road

Morgantown, West Virginia 26505-2888

Phone: **304-285-6374**

Email: **mark.hoover@cdc.hhs.gov**

The findings and conclusions in this presentation are those of the authors and do not necessarily represent the views of the National Institute for Occupational Safety and Health.

Mention of company names or products does not constitute endorsement by NIOSH.